




All you need to know

YOUR SRT TV REMOTE

1. TV input source select
2. TV/AUX power/standby
3. Shortcuts
Red: Live TV Yellow: Movies
Green: Shows Blue: Recordings
4. "A" Button - SRT TV Main Menu
5. DVR controls
6. Android Apps Menu
7. Navigation Arrows
8. Back
9. Volume up and down
10. Channel select and text entry
11. Information
12. Search
13. Infrared (IR) window
14. Microphone
15. Set Top Box power/standby
16. "B" Button – Replay TV
17. "C" Button – Settings
18. Electronic Program Guide
19. OK/Select
20. Home
21. Voice control – may have  or  icons
22. Channel/Page up and down
23. Mute
24. Subtitles/closed captions
25. Last channel recall
26. Low battery warning LED



YOUR SRT TV REMOTE CONT.






BUTTON FUNCTIONALITY

1. **TV input source select** / Changes video input on TV if remote is programmed with a TV infrared code.
2. **TV/AUX power/standby** / Powers on or off TV or auxiliary device if remote is programmed with a TV/Aux infrared code.
3. **Color navigation**

Red – LIVE TV / Tunes to the live segment of the last content viewed in SRT TV app.

Green – SHOWS / Displays the shows that are presently available for View On Demand (VOD) from SRT TV.

Yellow – MOVIES / Displays the movies that are presently available for Viewing On Demand (VOD) from SRT TV.

Blue – RECORDINGS / Displays the DVR recordings that you have recorded and are scheduled to record.
4. **“A” Button – Menu** / Displays the SRT TV main menu.
5. **DVR Controls**
 -  Fast rewinds VOD, DVR, or live TV.
 -  Stop or pause VOD, DVR or live TV.
 -  Play or pause toggle of VOD, DVR, or live TV.
 -  Fast forwards VOD, DVR, or live TV.
 -  Begin recording selected live TV content in the SRT TV app.
6. **Android App Menu** / Displays the Android TV Apps menu.
7. **Navigation Arrows** / Moves to highlight items in respective direction.
8. **Back** / Returns to previous menu or state within current app. From live video, this key opens the SRT TV Main Menu.
9. **Volume up and down** / Increases or decreases volume levels on your audio device(s).
10. **Channel select and text entry** / Enter channel numbers in the GUIDE or full screen video or use for text entry.
11. **Information** / Display details about the content being watched.
12. **Search** / Display SRT TV App search menu.
13. **Infrared (IR) window** / Sends IR signal to set top box when paired in IR mode.
14. **Microphone** / Used for in-app or Google voice search.
15. **Set Top Box power/standby** / Switches Set Top Box power on or into standby mode. Holding the button down for a couple of seconds will display a menu to restart set top box.
16. **“B” Button – Replay TV** / Displays the channels that are available for watching catchup TV on.
17. **“C” Button – Settings** / Displays the SRT TV App settings screen.
18. **Electronic Program Guide** / Displays the SRT TV Electronic Program Guide.
19. **OK/Select** / Short Press – Confirms a select. When watching video in SRT TV App, info on the current video playing appears, including time shift bar.

Long Press – Invokes the SRT TV in App search menu. This is the same function as the magnifying glass on the SRT TV Main Menu.
20. **Home** / Launches Android TV main menu including access to Apps.
21. **Google Voice control** / Launches voice-based Google Assistant search.
22. **Channel/Page up and down** / Selects the previous and next available channels. (Hold for rapid advance.) Within the GUIDE screen, scrolls one page up or down.
23. **Mute** / Mutes the audio.
24. **Subtitles/closed captions** / Toggles closed captions On/Off in SRT TV app
25. **Last channel recall** / Displays the last 15 watched items.
26. **Low battery warning LED** / LED will flash when batteries are getting low.